

- SF Asennusohje
- S Installation instruktioer
- N Installationsinstruktioner
- DK Installationsinstruktus
- NL Installatievoorschrift
- D Montageanweisung
- F Instructions d'installation
- ES Instrucciones de montaje
- I Istruzioni di montaggio

M41A15

ASENNUSOHJE/ INSTALLATION INSTRUCTIONS

≈80 mm

≈100 mm

A1-A5

A1

A2

A3

A4

3 mm

8 mm

1.5 mm² max.

A5

3	Y	0(2)...10 Vdc	Y
2	24 V⊥	0%	24 V⊥
1	24 V~	100%	24 V~

